









































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Info		Info
	Back		Back
	Vol +		Vol +
	Vol -		Vol -
	Nicam / A2		3D
	Sleep		Sleep
	CH +		Ch +
	CH -		Ch -
	Menu		Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Exit		Exit
	Mode		Media
	TV / Radio		TV/R
	Freeze		Pause
	Subtitle		Subt
	Text		Text
	P.Mode		Shift + Format
	S.Mode		Dual





Original		Replacement		Original	Replacement
	Mix		Smart		
	Hold		Stop		
	Index		Shift + Info		
	Subpage		AV		
	Reveal		D. Menu		
	Red		Red		
	Green		Green		
	Size		Format		
	Yellow		Yellow		
	Blue		Blue		
	Zoom		Eject		
	Fav-CH		Pre Ch		
	EPG		Guide		
	CH List		List		

