



Original	Replacement
Power On	Power
Standby	Shift + Power
DVI	Shift + 1
Display Port	Shift + 2
VGA	Shift + 3
RGB / HV	Shift + 4
HDMI	Shift + 5
DVD/HD	Shift + 6
VIDEO	Shift + 7
S-Video	Shift + 8
Picture Mode	Shift + Format
Aspect	Format
Sound	Dual
Option	Options
1	1
2	2
3	3

Original	Replacement
4	4
5	5
6	6
7	7
8	8
9	9
0	0
--	Shift + Guide
ENT	Pre Ch
Display	Info
Menu	Menu
Up	Up
Left / -	Left
SET	Ok
Right / +	Right
Down	Down
Auto Set Up	Smart





Original		Replacement	
	Exit		Exit
	Vol+		Vol +
	Vol-		Vol -
	Guide		Guide
	Mute		Mute
	CH+		Ch +
	CH-		Ch -
	Still On/Off		Stop
	Still Capture		Rec
	[=]		Text
	PIP On/OFF		Red
	PIP Input		Green
	PIP Change		Yellow
	MTS		Media
	Audio Input		AV

Original	Replacement

