



Original	Replacement
Power	Power
Open/Close	Eject
Status	AV
PIP	3D
Audio	Dual
Miracast	TV/R
Internet	Shift + Media
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0

Original	Replacement
#	Guide
*/Cancel	Format
<<	<<
Play	Play
>>	>>
I<<	I<<
Pause	Pause
>>I	>>I
Stop	Stop
[...] / CC	Subt
X/Exit	Exit
Pop-Up Menu/Top Menu	Menu
Netflix	Media
Home	Smart
Option	Options
Return	Back
Up	Up





Original	Replacement	Original	Replacement
Down	Down		
Right	Right		
Left	Left		
OK	Ok		
Red	Red		
Green	Green		
Yellow	Yellow		
Blue	Blue		
Power Tv	Shift + Power		
AV Input Tv	Shift + AV		
Tv Vol+	Vol +		
Tv Vol-	Vol -		

