Mandis shop

Philips 996580005584

Original	Replacement
Power	Power
Play	Play
Audio In	Red
AUX	Green
Pause	Pause
Optical	Yellow
I<	I<<
>I	>>I
Bluetooth	Blue
HDMI IN	1
HDMI ARC	3
Vol +	Vol +
Mute	Mute
Vol -	Vol -
Sound	Dual
Treble+	Ch +
Treble-	Ch -

Original	Replacement
Audio Sync +	Right
Audio Sync -	Left
Bass+	Up
Bass-	Down
Settings Vol	Menu
Settings Delay	Info
Night	Media
DIM/Exit Setting	Exit