





































| Original | Replacement |
|--|--|
|  Power |  Power |
|  Mute |  Mute / Dimmer |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  -/-- |  Shift + Guide / EPG / -/-- |
|  Recall |  Back / Return |
|  Red |  Red / Netflix / Search |
|  Green |  Green / APP / Repeat |
|  Yellow |  Yellow / YouTube / Repeat |

| Original | Replacement |
|--|---|
|  Blue |  Blue / Prime Video / Random |
|  Source |  AV / Input / RDS |
|  Vol+ |  Vol+ |
|  Vol- |  Vol- |
|  CH+ |  CH+ / Page+ |
|  CH- |  CH- / Page- |
|  Audio |  Audio / Lang I/II |
|  Aspect |  Eject / Surround |
|  Display |  Display / Media |
|  Tv/Radio |  TV/Radio / |
|  Rec |  Rec / Rec Mode |
|  Up |  Up |
|  Left |  Left |
|  OK/CH List |  OK |
|  Right |  Right |
|  Down |  Down |
|  Menu |  Menu / Home |





| Original | | Replacement | |
|----------|-----------------|-------------|-----------------------|
| | Exit | | Exit / Cancel / Clear |
| | EPG | | Guide / EPG / -/-- |
| | P.Mode | | Picture / Format |
| | S.Mode | | Sound / Title |
| | Sleep | | Sleep / Timer |
| | Text | | Text / Goto |
| | PVR/Hold | | Setup / OPT / |
| | Size | | Zoom / Size |
| | FAV | | Fav / Marker / PC |
| | Play | | Play / Slow |
| | Pause/Timeshift | | Pause / Step / Freeze |
| | Stop/Auto | | Stop / Hold |
| | Reveal | | D.Menu / Top |
| | Subtitle | | Subtitle / EQ |
| | <</Nicam | | << / Tune- |
| | >>/Freeze | | >> / Tune+ |
| | I<</Index | | I<< / Preset- |

| Original | | Replacement | |
|----------|-------------|-------------|---------------|
| | >>I/Subpage | | >>I / Preset+ |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |

