



| Original  |        | Replacement   |                             | Original  |            | Replacement   |                       |
|---|--------|---|-----------------------------|---|------------|---|-----------------------|
|    | Power  |    | Power                       |    | TV         |    | Shift + 1             |
|    | 1      |    | 1                           |    | Up / P+    |    | Shift + Up            |
|    | 2      |    | 2                           |    | Up / P+    |    | Up                    |
|    | 3      |    | 3                           |    | AV         |    | AV / Input / RDS      |
|    | 4      |    | 4                           |    | Left / V-  |    | Left                  |
|    | 5      |    | 5                           |    | Left / V-  |    | Shift + Left          |
|    | 6      |    | 6                           |    | Menu       |    | Menu / Home           |
|    | 7      |    | 7                           |    | Menu       |    | Shift + Menu /        |
|    | 8      |    | 8                           |    | Right / V+ |    | Right                 |
|   | 9      |   | 9                           |   | Right / V+ |   | Shift + Right         |
|  | Mute   |  | Mute / Dimmer               |  | S / M / D  |  | Exit / Cancel / Clear |
|  | 0      |  | 0                           |  | Down / P-  |  | Shift + Down          |
|  | 16:9   |  | Picture / Format            |  | Down / P-  |  | Down                  |
|  | Red    |  | Red / Netflix / Search      |  | Recall     |  | Back / Return         |
|  | Green  |  | Green / APP / Repeat        |  | Recall     |  | Shift + Back / Return |
|  | Yellow |  | Yellow / YouTube / Repeat   |  | i          |  | Info / Angle          |
|  | Blue   |  | Blue / Prime Video / Random |  | EQ         |  | Subtitle / EQ         |





| Original  | Replacement  |
|---|--|
|  | ≡i<br> +  Shift + Info / Angle |
|  | PP<br> Title / Sound  |
|  | ≡<br> Text / Goto   |
|  | ≡/≡<br> Setup / OPT /   |
|  | Hold<br> Stop / Hold  |
|  | Size<br> Zoom / Size  |
|  | ≡X<br> Sleep / Timer  |
|  | ≡?<br> D.Menu / Top   |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |
|   |  |

| Original | Replacement |
|----------|-------------|
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |

