












































Original	Replacement
 POWER	 Power
 SOURCE	 AV / Input / RDS
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TTX/MIX	 Text / Goto
 PRE-CH	 Fav / Marker / PC
 VOL+	 Vol+
 VOL-	 Vol-
 MUTE	 Mute / Dimmer

Original	Replacement
 CH+	 CH+ / Page+
 CH-	 CH- / Page-
 CH LIST	 Smart / List
 MENU	 Menu / Home
 MEDIA.P	 Display / Media
 GUIDE	 Guide / EPG / -/-
 TOOLS	 Setup / OPT /
 INFO	 Info / Angle
 RETURN	 Back / Return
 EXIT	 Exit / Cancel / Clear
 UP	 Up
 DOWN	 Down
 RIGHT	 Right
 LEFT	 Left
 OK	 OK
 RED	 Red / Netflix / Search
 GREEN	 Green / APP / Repeat





Original	Replacement	Original	Replacement
 YELLOW	 Yellow / YouTube / Repeat		
 BLUE	 Blue / Prime Video / Random		
 AD	 Audio / Lang I/II		
 P.SIZE	 Zoom / Size		
 SUBT.	 Subtitle / EQ		

Original	Replacement

