






































Original	Replacement
 Power	 Power
 Open / Close	 Eject / Surround
 Dimmer	 Shift + Mute / Dimmer
 BD	 Shift + 2
 Tuner	 Shift + 6
 AUX	 Shift + 7
 1 / RDS Display	 1
 2	 2
 3 / TA	 3
 4 / PTY-	 4
 5 / PTY Search	 5
 6 / PTY+	 6
 7	 7
 8	 8
 9	 9
 Audio	 Audio / Lang I/II
 0	 0

Original	Replacement
 Subtitle	 Subtitle / EQ
 I<<	 I<< / Preset-
 Mo/St / Slow	 Display / Media
 Pause	 Pause / Step / Freeze
 >>I	 >>I / Preset+
 <<	 << / Tune-
 Stop	 Stop / Hold
 Play	 Play / Slow
 >>	 >> / Tune+
 Vol+	 Vol+
 Mute	 Mute / Dimmer
 Tuning+ / CH+	 CH+ / Page+
 Vol-	 Vol-
 Step	 Shift + Pause / Step /
 Tuning- / CH-	 CH- / Page-
 Menu	 Menu / Home
 Return	 Back / Return





Original	Replacement
	
Up	Up
	
Left	Left
	
Enter	OK
	
Right	Right
	
Info	Info / Angle
	
Down	Down
	
Exit	Exit / Cancel / Clear
	
Red	Red / Netflix / Search
	
Green	Green / APP / Repeat
	
Yellow	Yellow / YouTube / Repeat
	
Blue	Blue / Prime Video / Random
	
PopUp Menu / Title Menu	Shift + D.Menu / Top Menu
	
Disc Menu	D.Menu / Top
	
Dolby PL. II Mode	Shift + Sound / Title
	
Dolby PL. II Effect	Sound / Title
	
Tuner Memory	Rec / Rec Mode
	
PIP	Picture / Format

Original	Replacement
	
SFE Mode	Smart / List
	
DSP	Setup / OPT /
	
Repeat	Shift + Green / APP /
	
Repeat A-B	Shift + Yellow / YouTube /
	
Zoom	Zoom / Size
	
Sleep	Sleep / Timer

