







































































Original	Replacement	Original	Replacement
	Power		Power
	[≡]		Text / Goto
	[≡?]		D.Menu / Top
	[...]		Subtitle / EQ
	[≡+]		Eject / Surround
	[≡o]		Sound / Title
	[≡◆]		Zoom / Size
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Recall		Fav / Marker / PC
	0		0
	Source		AV / Input / RDS
	ATV		Shift + Smart / List
	DTV		Shift + Display / Media
	EPG		Guide / EPG / -/-
	Radio		TV/Radio /
	I/II/I+II/▼/O)		Audio / Lang I/II
	Vol+		Vol+
	P+		CH+ / Page+
	P.Info		Display / Media
	Mute		Mute / Dimmer
	Vol-		Vol-
	P-		CH- / Page-
	[i+]		Info / Angle
	[<>]		Picture / Format
	Sleep		Sleep / Timer
	AV Mode		Shift + AV / Input / RDS





Original		Replacement		Original		Replacement	
	Menu		Menu / Home		Option		Setup / OPT /
	Up		Up		Rec		Rec / Rec Mode
	Left		Left		Rec Stop		Shift + Stop /
	OK		OK		Stop		Stop / Hold
	Right		Right				
	End		Exit / Cancel / Clear				
	Down		Down				
	Back		Back / Return				
	Red		Red / Netflix / Search				
	Green		Green / APP / Repeat				
	Yellow		Yellow / YouTube / Repeat				
	Blue		Blue / Prime Video / Random				
	Action		Smart / List				
	Power Aquos Link		Shift + Power				
	<<		<< / Tune-				
	Play		Play / Slow				
	>>		>> / Tune+				

