







































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	FAV		Pre Ch
	Subtitle		Subt
	Info		Info
	TTX		Text
	Recall		Back
	List		List
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Menu		Menu
	Exit		Exit
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	EPG		Guide
	Timer		AV
	Pg Dn		Media
	Pg Up		Smart
	Vol+		Vol +
	Vol-		Vol -
	<<		<<
	>>		>>
	<<		<<





Original		Replacement		Original	Replacement
	>>I		>>I		
	CH+		Ch +		
	Ch-		Ch -		
	Play		Play		
	Pause		Pause		
	Stop		Stop		
	Audio		Dual		
	Rec		Rec		
	Sleep		Sleep		
	TV / Radio		TV/R		
	Aspect		Format		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		

