Mandis shop

RMT-812

Original	Replacement	Original	Replacement
Photo	Smart / List	<I / I<	Left
Zero Set	Setup / OPT /	Stop	Stop / Hold
Start/Stop	Power	>I / II>	Right
Display	Display / Media	PAUSE	Pause / Step / Freeze
Data Code	Menu / Home	SLOW I>	Slow I>	Sleep / Timer
T	Up	×2	X2	Zoom / Size
Play Memory	Exit / Cancel / Clear	MARK	Mark	Fav / Marker / PC
Index Memory	Info / Angle	AUDIO DUB	Audio / Lang I/II
Memory-	Vol -		
Memory+	Vol +		
W	Down		
Search Mode	Red / Netflix / Search		
I<<	I<< / Preset-		
>>I	>>I / Preset+		
<<	<< / Tune-		
Play	Play / Slow		
>>	>> / Tune+		

https://mandisshop.ie/en/Sony-10669836-replacement-remote-control-for-Sony-RMT-812-175363.htm