






























































































Original	Replacement	Original	Replacement
Power		Power	
Mute		Up	
1		Down	
2		Right	
3		Left	
4		Ok	
5		Vol+	
6		Vol-	
7		Sound	
8		Pic	
9		Ch+	
0		Ch-	
Audio		Sleep	
Recall		Aspect	
Tv Menu		Freeze	
Source		Tv/Radio	
ChList		Text	



Original	Replacement	Original	Replacement
Epg	 Guide	I<<	 I<<
Fav	 Pre Ch	>>I	 >>I
Info	 Info	Play	 Play
Red	 Red	Pause	 Pause
Green	 Green	Stop	 Stop
Yellow	 Yellow	Rec/Rep	 Rec
Blue	 Blue		
Reveal	 Media		
Hold	 D. Menu		
Index	 +  Shift + Info		
Subpage	 +  Shift + AV		
List	 Smart		
Mix	 Options		
Subtitle	 Subt		
Size	 3D		
<<	 <<		
>>	 >>		



Original	Replacement	Original	Replacement
Power		Vol+	 Vol +
Mute		Vol-	 Vol -
[I]/Menu		CH+	 Ch +
Exit		CH-	 Ch -
Source		Up	 Up
1		Down	 Down
2		Right	 Right
3		Left	 Left
4		OK	 Ok
5		Recall	 Back
6		Info	 Info
7		EPG	 Guide
8		Freeze	 Options
9		Red	 Red
0		Green	 Green
Subtitle		Yellow	 Yellow
Text		Blue	 Blue



