


















































































































Original	Replacement	Original	Replacement
	Power		Power
	Source		AV / Input / RDS
	TV		Shift + 1
	[<>]		Picture / Format
	3D		Shift + 3
	O)/II		Audio / Lang I/II
	Subtitle		Subtitle / EQ
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Recall		Fav / Marker / PC
	[i+]		Info / Angle
	AD		Sound / Title
	Vol+		Vol+
	Vol-		Vol-
	Mute		Mute / Dimmer
	P+		CH+ / Page+
	P-		CH- / Page-
	Text		Text / Goto
	Quick		Display / Media
	List		Smart / List
	Menu		Menu / Home
	Guide		Guide / EPG / -/-
	[.]		D.Menu / Top
	[>]		Setup / OPT /
	Exit		Exit / Cancel / Clear
	Up		Up





Original	Replacement	Original	Replacement
	Down		Down
	Right		Right
	Left		Left
	Back		Back / Return
	OK		OK
	>>		Shift + Right
	Play		Play / Slow
	<<		Shift + Left
	Stop		Stop / Hold
	Pause/Step		Pause / Step / Freeze
	↑↑		Shift + Up
	↓↓		Shift + Down
	Rec		Rec / Rec Mode
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	<</[≡+]		<< / Tune-
	Blue		Blue / Prime Video / Random
	>>/[≡◇]		>> / Tune+
	<</[≡?]		<< / Preset-
	>> /[O]/[≡x]		>> / Preset+
	[▼]		TV/Radio /

