





































































Original	Replacement	Original	Replacement
 Power	 Power	 Exit/Back	 Exit
 Mute	 Mute	 Up	 Up
 1	 1	 Left	 Left
 2	 2	 OK	 Ok
 3	 3	 Right	 Right
 4	 4	 Down	 Down
 5	 5	 P+	 Ch +
 6	 6	 P-	 Ch -
 7	 7	 Vol+	 Vol +
 8	 8	 Vol-	 Vol -
 9	 9	 [<<>>]	 Format
 0	 0	 TV/R	 TV/R
 Recall	 Pre Ch	 [i+] / [≡i]	 Info
 Source	 AV	 Text / [≡] / [≡]	 Text
 Menu/DVD	 Menu	 Pause	 Pause
 Guide	 Guide	 Play / I/II	 Play
 [ ] [ ]	 3D	 Play / I/II	 Dual































































































Original		Replacement		Original	Replacement
	◀◀ / [≡◂]		<<		
	◀◀ / [≡◂]		Options		
	▶▶ / Subtitle		Subt		
	▶▶ / Subtitle		>>		
	▲		Smart		
	■ / [≡□]		Stop		
	⏏ / [≡⇕]		Eject		
	⏏ / [≡⇕]		l<<		
	▶▶ / [⊖][≡X]		>>l		
	▶▶ / [⊖][≡X]		Back		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		





























































Original	Replacement	Original	Replacement
 Power	 Power	 Right	 Right
 Mute	 Mute	 Down	 Down
 1	 1	 Vol+	 Vol +
 2	 2	 Vol-	 Vol -
 3	 3	  / [v]	 Pause
 4	 4	  / I/II	 Play
 5	 5	  / I/II	 Dual
 6	 6	  / [≡●]	 <<<
 7	 7	  / [≡●]	 TV/R
 8	 8	  / Subtitle	 >>>
 9	 9	  / Subtitle	 Subt
 0	 0	  ▲	 Smart
  Menu/DVD	  Menu	  / [≡□]	 Stop
  Exit/Back	  Exit	  / [≡⇅]	 Eject
  Up	  Up	  / [≡⇅]	 I<<<
  Left	  Left	  / [⊙][≡X]	 >>>I
  OK	  Ok	  / [⊙][≡X]	 Back





Original	Replacement	Original	Replacement
 Power	 Power	 Mute	 Mute
 1	 1	 2	 2
 3	 3	 4	 4
 5	 5	 6	 6
 7	 7	 8	 8
 9	 9	 0	 0
 Source	 AV	 P+	 Ch +
 P-	 Ch -	 Vol-	 Vol -
 Vol+	 Vol +		

Original	Replacement	Original	Replacement
 Pause	 Pause	 Play	 Play
 Fast Forward	 Fast Forward	 Fast Reverse	 Fast Reverse
 Stop	 Stop	 Subtitles	 Subtitles
 Smart	 Smart	 Eject	 Eject
 Back	 Back	 Fast Forward	 Fast Forward
 Fast Forward	 Fast Forward		

