



| Original | Replacement | Original | Replacement |
|---|---|--|---|
|  Power |  Power |  -- |  Guide / EPG / -/-- |
|  Up / P+ |  Up |  0 |  0 |
|  Up / P+ |  CH+ / Page+ |  P < P |  Fav / Marker / PC |
|  Menu |  Menu / Home |  PP |  Back / Return |
|  Left |  Left |  Vol+ |  Vol+ |
|  Right |  Right |  I-II |  Audio / Lang I/II |
|  Down / P- |  Down |  Mute |  Mute / Dimmer |
|  Down / P- |  CH- / Page- |  Vol- |  Vol- |
|  1 |  1 |  Info |  Info / Angle |
|  2 |  2 |  Red |  Red / Netflix / Search |
|  3 |  3 |  Green |  Green / APP / Repeat |
|  4 |  4 |  Yellow |  Yellow / YouTube / Repeat |
|  5 |  5 |  Blue |  Blue / Prime Video / Random |
|  6 |  6 |  [TV] |  Shift + 1 |
|  7 |  7 |  [TV] |  TV/Radio / |
|  8 |  8 |  [AV] |  AV / Input / RDS |
|  9 |  9 |  [≡] |  Text / Goto |








































































| Original | Replacement | Original | Replacement |
|---|-------------|---|-----------------------------|
|  | Power |  | Power |
|  | Up / P+ |  | Up |
|  | Up / P+ |  | CH+ / Page+ |
|  | Menu |  | Menu / Home |
|  | Left |  | Left |
|  | Select |  | OK |
|  | Right |  | Right |
|  | Down / P- |  | CH- / Page- |
|  | Down / P- |  | Down |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | +10 |  | Guide / EPG / -/- |
|  | 0 |  | 0 |
|  | Repeat |  | Green / APP / Repeat |
|  | Search |  | Red / Netflix / Search |
|  | A→B |  | Yellow / YouTube / Repeat |
|  | Display |  | Display / Media |
|  | Audio |  | Audio / Lang I/II |
|  | Subtitle |  | Subtitle / EQ |
|  | Zoom |  | Zoom / Size |
|  | Prog |  | TV/Radio / |
|  | C |  | Blue / Prime Video / Random |
|  | Angle |  | Info / Angle |
|  | Return |  | Back / Return |
|  | Time |  | Sleep / Timer |
|  | << |  | << / Tune- |
|  | >> |  | >> / Tune+ |





| Original | Replacement | Original | Replacement |
|-------------|---|------------|---|
| On/Off |  Power | Menu Right |  Right |
| Mute |  Mute / Dimmer | Menu Down |  Down |
| Txt Stop |  Stop / Hold | Back |  Back / Return |
| Tone+ |  >> / Tune+ | Volume+ |  Vol+ |
| Lang |  Sound / Title | Chan.Up |  CH+ / Page+ |
| Menu audio |  Audio / Lang I/II | Volume- |  Vol- |
| Subt.List |  Subtitle / EQ | Display |  Display / Media |
| Txt Expand |  Zoom / Size | Chan.Down |  CH- / Page- |
| Sleep Timer |  Sleep / Timer | 1 |  1 |
| Return TV |  TV/Radio / | 2 |  2 |
| Menu video |  D.Menu / Top | 3 |  3 |
| Text |  Text / Goto | 4 |  4 |
| Menu |  Menu / Home | 5 |  5 |
| Menu Up |  Up | 6 |  6 |
| Info |  Info / Angle | 7 |  7 |
| Menu Left |  Left | 8 |  8 |
| OK Enter |  OK | 9 |  9 |

| Original | Replacement | Original | Replacement |
|------------|---|-----------|---|
| Menu Right |  Right | Menu Down |  Down |
| Menu Down |  Down | Back |  Back / Return |
| Back |  Back / Return | Volume+ |  Vol+ |
| Volume+ |  Vol+ | Chan.Up |  CH+ / Page+ |
| Chan.Up |  CH+ / Page+ | Volume- |  Vol- |
| Volume- |  Vol- | Display |  Display / Media |
| Display |  Display / Media | Chan.Down |  CH- / Page- |
| Chan.Down |  CH- / Page- | 1 |  1 |
| 1 |  1 | 2 |  2 |
| 2 |  2 | 3 |  3 |
| 3 |  3 | 4 |  4 |
| 4 |  4 | 5 |  5 |
| 5 |  5 | 6 |  6 |
| 6 |  6 | 7 |  7 |
| 7 |  7 | 8 |  8 |
| 8 |  8 | 9 |  9 |
| 9 |  9 | | |



