Mandis shop

MX009

Original		Replacement		Original	Replacement
POWER	Power		Power		
MUTE	Mute	MUTE	Mute		
FRONT+	Front+		Up		
FRONT-	Front-		Down		
CEN+	Cen+		Right		
CEN-	Cen-		Left		
SURR+	Surr+	+ CH	Ch +		
SURR-	Surr-	CH −	Ch -		
TRE+	Tre+	1	1		
TRE-	Tre-	4	4		
BASS+	Bass+	2	2		
BASS-	Bass-	5	5		
SUB+	Sub+	3	3		
SUB-	Sub-	6	6		
VOL+ MASTER	Master Vol+	+ VOL	Vol +		
MASTER VOL-	Master Vol-	VOL −	Vol -		

https://mandisshop.ie/en/MxOnda/1060879-91184-replacement-remote-control-for-MxOnda-MX009.html