Original		Replacement	
POWER	Power		Power
OPEN/CLOSE	Open/Close	FAV 2. P/C	P/C / FAV
FUNCTION	Function	MEDIA	MEDIA
SLEEP	Sleep	EPG 1. -/--	-/-- / EPG
TITLE	Title	WIDE	WIDE
DISPLAY	Display	INFO	INFO
MENU	Menu	MENU	MENU
SETUP	Setup	VOD	VOD
	Preset Up		UP
	Preset Down		DOWN
	Left/Tun-		LEFT
	Right/Tun+		RIGHT
ENTER	Enter	OK	OK
RETURN	Return	BACK	BACK
REC	Rec		Rec
STOP	Stop		Stop
MO./ST. PLAY	Play/Mb/St.		Play

Original		Replacement	
PAUSE/STEP	Pause//Step		Pause
SKIP	I<< Skip		First
	<<Scan		Rewind
	>>Scan		Fast Forward
SKIP	>>I Skip		Last
TV→HT SPK	Audio/Tv→HT SPK		Audio
MUTE	Mute		MUTE
VOL +	Vol +	VOL +	VOL +
VOL −	Vol -	VOL −	VOL -
LG EQ	♫LG-EQ	OPT+	OPT+
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7

Original		Replacement		Original	Replacement
8	8	8	8		
9	9	9	9		
0	0	0	0		
REPEAT RANDOM	Random/ Repeat	TEXT	TEXT		
SUBTITLE	[. . .] / Subtitl		Subt.		
POWER	Power Tv	SHIFT +	Shift + Power		
+ PR/CH	PR/ CH+Tv	+ CH	CH +		
PR/CH −	PR/ CH- Tv	CH −	CH -		
VOL −	Vol - Tv	SHIFT +	Shift + LEFT		
+ VOL	Vol +Tv	SHIFT +	Shift + RIGHT		
PROG.MEMO	Prog. Memo	V-FOR	V- FOR		
CLEAR	Clear	EXIT	EXIT		
RDS RESOLUTION	RDS	TV/R	TV/ R		
RESOLUTION PTY	PTY/ Resolution	SRC	SRC		
EQ	EQ♪	SHIFT +	Shift + Audio		
INPUT	Input Tv	SHIFT + SRC	Shift + SRC		