Original		Replacement	
	Power		Power
	Tv Source/		AV / Input / RDS
	Sleep		Sleep / Timer
	1/RDS Display		1
	2		2
	3/TA		3
	4/PTY-		4
	5/PTY Search		5
	6/PTY+		6
	7		7
	8		8
	9		9
	0		0
	Vol +		Vol +
	Mute		Mute / Dimmer
	CH+		CH+ / Page+
	Vol -		Vol -

Original		Replacement	
	Tv Sound		Sound / Title
	CH-		CH- / Page-
	Home		Menu / Home
	Tools		Setup / OPT /
	Up		Up
	Info		Info / Angle
	Left		Left
	Enter		OK
	Right		Right
	Return		Back / Return
	Down		Down
	Exit		Exit / Cancel / Clear
	Red/A		Red / Netflix / Search
	Green/B		Green / APP / Repeat
	Yellow/C/Tuner Memory		Yellow / YouTube / Repeat
	Blue/D/MO/ST		Blue / Prime Video / Random
	HUB/Smart		Smart / List

Original	Replacement	Original	Replacement
SEARCH Search	SHIFT + NETFLIX SEARCH Shift + Red / Netflix /		

Original		Replacement	
	Power		Power
	Tv		AV / Input / RDS
	Open/Close		Eject / Surround
	Sleep		Sleep / Timer
	1/RDS Display		1
	2		2
	3/TA		3
	4/PTY-		4
	5/PTY Search		5
	6/PTY+		6
	7		7
	8		8
	9		9
	Disc Menu		D.Menu / Top
	0		0
	Title Menu/Popup		Display / Media
	I<<		I<< / Preset-

Original		Replacement	
	>>I		>>I / Preset+
	<<		<< / Tune-
	>>		>> / Tune+
	Stop		Stop / Hold
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Vol +		Vol +
	Mute		Mute / Dimmer
	Tuning/CH+		CH+ / Page+
	Vol -		Vol -
	Tv Sound		Sound / Title
	Tuning/CH-		CH- / Page-
	Full Screen		Text / Goto
	Home		Menu / Home
	Repeat		Shift + Green / APP /
	Tools		Setup / OPT /
	Up		Up

Original		Replacement		Original		Replacement	
INFO	Info	ANGLE INFO	Info / Angle	SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
◄	Left	◄	Left	SOUND EFFECT	Effect/Sound	PROGRAM TV/RADIO	TV/Radio /
Enter		OK	OK				
►	Right	►	Right				
RETURN	Return	RETURN BACK	Back / Return				
▼	Down	▼	Down				
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
A	Red/A	NETFLIX SEARCH	Red / Netflix / Search				
B	Green/B	APP REPEAT	Green / APP / Repeat				
C	Yellow/C/Tuner Memory	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
D	Blue/D/MO/ST	Prime Video RANDOM	Blue / Prime Video / Random				
SMART HUB	HUB/Smart	LIST SMART	Smart / List				
SEARCH	Search	SHIFT +	NETFLIX SEARCH	Shift + Red / Netflix /			
S/W LEVEL	S/W Level	FORMAT PICTURE	Picture / Format				
3D SOUND	3D Sound	SHIFT +	CD-STB 3	Shift + 3			
MANUAL PRESET	Preset/Manual	-/-- GUIDE EPG	Guide / EPG / -/--				
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II				