| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | Guide | Guide |
| 1 | 1 | ? | Dual |
| 2 | 2 | Exit | Exit |
| 3 | 3 | Menu | Menu |
| 4 | 4 | Back | Back |
| 5 | 5 | Tools | Options |
| 6 | 6 | @ | TV/R |
| 7 | 7 | Up | Up |
| 8 | 8 | Down | Down |
| 9 | 9 | Right | Right |
| 0 | 0 | Left | Left |
| FAV | Pre Ch | OK | Ok |
| TXT | Text | Vol + | Vol + |
| Red | Red | Vol - | Vol - |
| Green | Green | PR+ | Ch + |
| Yellow | Yellow | PR- | Ch - |
| Blue | Blue | Source | AV |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| | Mute | MUTE | Mute | | |
| | I< | | I<< | | |
| | >I | | >>I | | |
| | << | | << | | |
| | >> | | >> | | |
| | Rec | REC MODE | Rec | | |
| | Play | PLAY MODE | Play | | |
| | Pause | | Pause | | |
| | Stop | | Stop | | |
| 3D | 3D | ECO 3D | 3D | | |
| | Q | PICTURE FORMAT | Format | | |
| | [...].. | AD SUBT | Subt | | |
| NETFLIX | Netflix | SHIFT + APP MEDIA | Shift + Media | | |
| MY MEDIA | My Media | APP MEDIA | Media | | |
| | | | | | |
| | | | | | |
| | | | | | |