Mandis shop

RMT-AH410U

Original	Replacement
Power	Power
Input	AV
Auto Sound	Smart
Standard	Options
Cinema	Media
Music	Dual
Voice	TV/R
Night	Exit
Vol +	Vol +
Vol -	Vol -
Mute	Mute
Bass	Subt
Play Mode	Shift + Play
Audio	Shift + Dual
Up	Up
Down	Down
Enter	Ok

Original	Replacement
Play	Play
Pause	Pause
>>I	>>I
I <<	I <<

https://mandisshop.com/Sony-10634-255-replacement-remote-control-for-Sony-RMT-AH410U-1-48358-11.html