Mandis shop

BOSE ROOMMATE

Original		Replacement	
	On / Off		Power
	Mute / Mute All		Mute / Dimmer
	Up		Up
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	I<<		I<< / Preset-
	Volume+		Vol+
	Volume-		Vol-
	>>I		>>I / Preset+
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	Shuffle		Blue / Prime Video / Random
	Repeat		Green / APP / Repeat
	Playlist		Smart / List

Original		Replacement	
	Setup		Setup / OPT /

https://mandisshop.ie/en/BOSE/1062351-93729-replacement-remote-control-for-BOSE-ROOMMATE.html