Mandis shop

# Sanyo CXWF

| Original | Replacement |
|---|---|
| Power | Power |
| Computer | Comp / Video |
| Video | Shift + Comp / Video |
| Menu | Menu |
| Keystone | Shift + Up |
| Up | Up |
| Down | Down |
| Right | Right |
| Left | Left |
| Vol+ | Vol + / Page + |
| Vol- | Vol - / Page - |
| Select | Enter |
| D.Zoom+ | + / Play |
| D.Zoom- | - / Stop |
| Auto PC | Auto |
| Image | Eco / Aspect |
| Freeze | Freeze / Timer |

| Original | Replacement |
|---|---|
| P-Timer | Shift + Freeze / Timer |
| No Show | Source |
| Mute | Blank / Mute |
| Lamp Control | 3D / Invert |

https://mandisshop.ie/en/1063236-21665-replacement-remote-control-for-Sanyo-CXWF-6450909498.html