Mandis shop

Toshiba STORE TV2

Original	Replacement
Standby	Power
TV Sys	TV/R
Info	Info
Zoom	Eject
Select	Options
Audio	Dual
Subtitle	Subt
Repeat	Text
Home	Smart
Menu	Menu
Return	Back
Up	Up
Down	Down
Right	Right
Left	Left
Play	Play
Enter	Ok

Original	Replacement
Pause	Pause
<<	<<
>>	>>
I <<	I <<
Stop	Stop
>>I	>>I
Vol +	Vol +
Vol -	Vol -
Mute	Mute

https://mandis.tv/en/Toshiba/1613-225-replacement-remote-control-for-Toshiba-Store-TV2.htm