Mandis shop

10032435




| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| ON/OFF | On/Off | | Power | | | | |
| SPEED | Speed | HOME SMART | Smart | | | | |
| MODE | Mode | PICTURE FORMAT | Format | | | | |
| TIMER | Timer | TIMER AV | AV | | | | |
| SWING | Swing | APP MEDIA | Media | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |
| | | | | | | | |

https://mandisshop.ie/en/Klarstein/1064679-84983-replacement-remote-control-for-Klarstein-10032435.html