Mandis shop

TSP40EA

Original		Replacement		Original	Replacement
OSC	OSC	OPT-TOOLS SETUP	Setup / OPT /		
SPEED	Speed	MEDIA DISPLAY	Display / Media		
ION	ION	-/-- GUIDE EPG	Guide / EPG / -/--		
TIMER	Timer	TIMER SLEEP	Sleep / Timer		
MIST	Mist	HOME MENU	Menu / Home		
MODE	Mode	FORMAT PICTURE	Picture / Format		
MOSQUITO	Mosquito	LIST SMART	Smart / List		
ON/OFF	On/Off		Power		

https://mandisshop.ie/en/Ecron/1066560-96549-replacement-remote-control-for-Ecron-TSP40-EA.html