Mandis shop

Hisense EN205A7H

Original		Replacement	
Power		Power	
Mute		Mute / Dimmer	
Movie		TV/Radio /	
Music		Audio / Lang I/II	
Vol+		Vol+	
Vol+		Up	
I<		I<< / Preset-	
I<		Left	
Play		Play / Slow	
Pause		Pause / Step / Freeze	
Pair		OK	
>I		>>I / Preset+	
>I		Right	
Vol-		Vol-	
Vol-		Down	
News		Info / Angle	
HDMI ARC		0	

Original		Replacement	
OPT Coax		Setup / OPT /	
Bluetooth		9	
Line In		3	
USB		8	

https://mandisshop.ie/en/Hisense/1066905-96374-replacement-remote-control-for-Hisense-EN205A7H-WT0039938.html