Original		Replacement	
	Power		Power
	Mute	MUTE	Mute
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
	Tv/Radio	SEARCH TV/R	TV/R
	Recall	RETURN BACK	Back
i	i	DISPLAY INFO	Info
L/R	L/R	APP MEDIA	Media
	Play	PLAY MODE	Play

Original		Replacement	
	Pause		Pause
MENU	Menu	TOP MENU MENU	Menu
EXIT	Exit	CLEAR EXIT	Exit
DIGEST	Digest	SETTINGS OPT	Options
FAV	FAV	FAV PRE-CH	Pre Ch
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
SCAN	Scan	HOME SMART	Smart
EDIT	Edit	ECO 3D	3D
EPG	EPG	-/-- GUIDE	Guide
EPG	Red	A	Red
AUDIO	Green	B	Green
SUBTITLE	Yellow	C	Yellow
TTX	Blue	D	Blue

Original		Replacement	
AUDIO	Audio	SOUND DUAL	Dual
SUBTITLE	Subtitle	AD SUBT	Subt
TTX	TTX	REPEAT TEXT	Text

Original	Replacement