Mandis shop

RC- 1020

Original	Replacement	Original	Replacement
Open/Close	Eject	Repeat	Text
1	1	A-B	Pre Ch
2	2	Super Audio CD Setup	Menu
3	3	Title	List
4	4	Artist	Media
5	5	Display	Info
6	6	Time	AV
7	7	Pause	Pause
8	8	Play	Play
9	9	Stop	Stop
0	0	>>I	>>I
+10	Guide	I <<	I <<
Clear	Exit	>>	>>
Direct	TV/R	<<	<<
Program	Sleep		
Call	Back		
Random	Smart		

https://mandisshop.nl/en/1025-878-replacement-remote-control-for-RC-1020-DENON.html