Mandis shop

RMT- 156

Original		Replacement		Original	Replacement
POWER	Power		Power		
TV/VTR	Tv/ VTR	SEARCH TV/R	TV/ R		
CHANNEL +	Channel +	+ CH	Ch +		
CHANNEL -	Channel -	CH −	Ch -		
	Rec	REC MODE	Rec		
PLAY	Pl ay	PLAY MODE	Pl ay		
REW	<<		<<		
FF	>>		>>		
STOP	St op		St op		
PAUSE	Pause		Pause		

https://mandisshop.tv/Sony-106384-replacement-remote-control-for-Sony-RMT-156-138852.htm