Mandis shop

Yamaha RAV22

Original		Replacement	
DVD	DVD	DVD 2	2
DTV/CBL	DTV/CBL	TV 1	1
VCR	VCR	VIDEO 4	4
POWER	Power		Power
CD	CD	CD-STB 3	3
MD/CD-R	MD/CD-R	USB 8	8
V-AUX	V-AUX	AUX-HDD 7	7
MULTI CH IN	Multi CH In	TAPE 5	5
TUNER	Tuner	TUNER 6	6
A/B/C/D/E	A/B/C/D/E	LIST SMART	Smart / List
– PRES	Preset-	PRESET- ⏮	I<< / Preset-
RESET +	Preset+	PRESET+ ⏭	>>I / Preset+
STANDARD	Standard	TITLE SOUND	Sound / Title
5CH STEREO	5CH Stereo	LANG I/II AUDIO	Audio / Lang I/II
NIGHT	Night	SURROUND ⏏	Eject / Surround
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TEST	Test	GOTO TEXT	Text / Goto

Original		Replacement	
+ VOLUME	Vol +	+ VOL	Vol +
STRAIGHT	Straight	EQ SUBTITLE	Subtitle / EQ
PROG –	Prog-	CH PAGE –	CH- / Page-
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PROG +	Prog+	+ CH PAGE	CH+ / Page+
LEVEL	Level	MEDIA DISPLAY	Display / Media
VOLUME –	Vol -	VOL –	Vol -
SET MENU	Set Menu	HOME MENU	Menu / Home
	Up	▲	Up
	Down	▼	Down
–	-	◀	Left
+	+	▶	Right

https://mandisshop.eu/Yamaha-1560-188-replacement-remote-control-for-Yamaha-RAV22-WG70720.htm